

## Schritt-für-Schritt-Anleitung Austausch der NZ6 inception Kappen



### 1. Gewinde prüfen

Beim Wechsel der Kappe prüfen Sie zuerst, ob der schwarze Gewinding der alten Kappe noch auf dem Zielfernrohr sitzt.

Das sichtbare Gewinde am Zielfernrohr muss **silberfarben** sein.

**Richtig:** Der schwarze Gewinding wurde bereits entfernt.

**Falsch:** Der schwarze Gewinding befindet sich noch auf dem Zielfernrohr.



### 2. Gewinding entfernen

Falls der Ring fest sitzt, schrauben Sie ihn vorsichtig gegen den Uhrzeigersinn ab – bei Bedarf mit einem Gummigriff oder Lederlappen für besseren Halt.



### 3. Kappe aufschrauben

Sobald der alte Gewinding entfernt ist, können Sie die neue Kappe problemlos auf das silberne Gewinde aufschrauben.

## Step-by-step instructions. Replacing the NZ6 inception caps.



### 1. Check the threads.

Before changing the cap, check to see if the black threaded ring from the old cap is still on the rifle scope.

The visible threads on the rifle scope must be **silver**.

**Correct:** The black threaded ring has been removed.

**Incorrect:** The black threaded ring is still



### 2. Remove the threaded ring.

If the ring is tight, carefully unscrew it counterclockwise. Use a rubber grip, or leather rag to get a better hold, if necessary.



### 3. Screw on the cap

After removing the old threaded ring, you can easily screw the new cap onto the silver thread.